JMSU Heated Stream Selector







Gas Sampling Probes

Heated Sample Lines

Sample Gas Coolers

Condensate Treatment

Accessories

Gas Conditioning Systems

Sample Gas
Converters

APPLICATION

- · For extractive gas analysis
- · For emission and process monitoring
- Stream selector up to four sample points to one analyzer
- · For hot-wet gas analysis

BENEFITS

- No change in flow velocity/pressure due to tube-size bore hole through ball valves maximum operational safety
- · No damage of analyzer in case of failure
- · No influence to sample gas
- · No cold spots
- · Low noise operation also in case of switching
- · Low and easy maintenance
- Easy mounting and integration in gas analysis systems

FEATURES

- · For two to four sample streams
- · 19" rack mounting, 3 HU or 4 HU
- · Consistent heating
- · Operating temperature up to 220 °C
- Low and high temperature status contact
- · "Fail safe" condition in case of power failure
- Power supply 115 or 230 VAC 50/60 Hz
- Stainless steel ball valves with full bore size for sample stream switching
- · Pneumatic actuated ball valves
- · Optical shift position indicator

www.jct.at

TECHNICAL DATA

Model	JMSU-2	JMSU-3	JMSU-4
Description	heated stream selector		
Number of sample points / Housing	2 / 19" 3 HU	3 / 19" 4 HU	4 / 19" 4 HU
	Operation		
Operating temperature	max. 220 °C		
Ambient temperature	-20°60 °C		
Operating pressure	max. 7 bara		
Heating-up time	approx. 30 min		
	Construction		
Dimensions over all (W x H x D)	3 HU: 483 x 134 x 410 mm, 4 HU: 483 x 178 x 410 mm		
Weight	approx. 8 kg		
Sample gas connections inlet / Outlet	8 mm pipe (rear side)		
Connection instrument air	6 mm "push in" (rear side)		
Sample gas wetted materials	SS316, PTFE		
Protection class	IP20 (EN 60529)		
Housing / Colour	aluminum, natural		
Approvals / Signs	CE		
	Electrics		
Power supply	230 VAC or 115 VAC 50/60 Hz		
Power consumption	320 VA (2 sample streams) to 640 VA (4 sample streams)		
Sensor for external temperature controller	2 wire Pt100 RTD, IEC 751		
Electrical connection	spring type terminals, clamping range 0.08 to 2.5 mm ²		

GAS FLOW DIAGRAMM

JMSU-2 Ball valve 1 W

Order code Description Order code Description 79.00105 JMSU-2 for two sample streams, 3 HU, 115 VAC 50/60 Hz 79.00100 JMSU-2 for two sample streams, 3 HU, 230 VAC 50/60 Hz 79.00106 JMSU-2 for three sample streams, 4 HU, 115 VAC 50/60 Hz 79.00101 JMSU-2 for three sample streams, 4 HU, 230 VAC 50/60 Hz 79.00107 JMSU-2 for four sample streams, 4 HU, 115 VAC 50/60 Hz 79.00102 JMSU-2 for four sample streams, 4 HU, 230 VAC 50/60 Hz

ORDER CODES











JCT Analysentechnik GmbH Werner Heisenberg-Strasse 4

sales@jct.at